



ПРОФЕССИОНАЛЬНЫЕ СУЧКОРЕЗЫ

R214V/R26V/R260A/...

ЗАПАСНЫЕ ЧАСТИ, СУЧКОРЕЗЫ



- Запасное опорное лезвие для сучкорезов
- *P16 с центральным болтом стопорной системы R901P

	 731151			 g
R214V	8042745	1	P14	155
R214V-BULK28	8177553	28	P14	4340
R26V	8254520	1	P-SL2-40/50/60	200
R216SL	8301408	1	P116-SL	190
R215V	8243227	1	P-SL-40/45/60	142
R214SL	8301392	1	P114-SL	155
R260A	8201814	1	P160	233
R716VCB	8255497	1	P16*	215
R680V	8042752	1	P180-70	205
R619V	8029494	1	P19-80	390

R430V-R516V

ЗАПАСНЫЕ ЧАСТИ, СУЧКОРЕЗЫ



- Запасные стопоры для сучкорезов и кусторезов
- Разной степени жесткости

	 731151			 g
R430V	8243265	1	P-SL, P-SL2, P114, P116 - all 40 cm	18
R440V	8254544	1	P-SL, P-SL2, P114, P116, P52-SL, P54-SL	18
R515VS	8046514	1	P14, P16, P180-70, P19-80, P160-60, P51	20
R516V	8200824	1	P160-75, P160-90, P51H, P280, P51H	20

R372H

ЗАПАСНЫЕ ЧАСТИ, СУЧКОРЕЗЫ



- Запасное опорное лезвие с винтами для опорных сучкорезов

	 731151			 g
R372H	8235406	1	P172-65 /-85, P172-SL	39