



Nº	CODE	DESCRIPTION	Nº	CODE	DESCRIPTION
1	BP905L01	MOTOR HOUSING	25	BP905L23	ANVIL BUSHING
2	BP905L02	PIN	26	BP905L24	REGULATOR VALVE
3	BP905L03	AIR INLET	27	BP905L25	O-RING
4	BP905L04	TRIGGER	28	BP905L26	HAMMER CASE
5	BP905L05	VALVE STEM	29	BP905L27	GASKET
6	BP905L06	VALVE BUSHING	30	BP905L28	SCREW M6X25 (8)
7	BP905L07	O-RING	31	BP905L29	VALVE BUSHING
8	BPC81731	VALVE SPRING	32	BP905L30	WASHER
9	BP905L08	O-RING	33	BP905L31	HAMMER CAGE
10	BP905L09	SPRING PIN (2)	34	BP905L32	HAMMER (2)
11	BP905L10	GASKET	35	BP905L33	HAMMER PIN (2)
12	BP905L11	REAR COVER	36	BP905L34	ANVIL 8"
13	BP905L12	BALL BEARING	37	BP905L35	O-RING
14	BP905L13	REAR END PLATE	38	BP905L36	RETAINING RING
15	BP905L14 BP905L14B	ROTOR	39	BP905L37	SPRING PIN
16	BP905L15 BP905L15B	ROTOR BLADE (6)	40	BP905L38	HANDLE
17	BP905L16	SPRING PIN (3)	41	BP905L39	SCREW M6X20 (4)
18	BP905L17	CYLINDER	42	BP905L40	REGULATOR KNOB
19	BP905L18	FRONT END PLATE	43	BP905L41	SCREW (2)
20	BP905L19	BALL BEARING	44	BP905L42	REGULATOR KNOB
21	BP905L20	REVERSE VALVE	46	BP905L43	BUSHING
22	BP905L21	O-RING	49	BP905L44	RUBBER RING
23	BPC81418	SPRING	50	BP905L45	RUBBER RING
24	BP905L22	PIN (2)	51	BP905L46	HEX.WRENCH 5MM




BP905L



***IMPORTANT:** for blades and rotors purchase orders, check first the thickness of the used blades and rotors:

3.9mm blade: BP905L15
4.9mm blade: BP905L15B
4mm rotor: BP905L14
5mm rotor: BP905L14B



SNA Europe does not cover the causes over negligence in tool use and/or repair, inadequate care, or abnormal usage conditions. Follow the instructions for proper use, safety, maintenance and servicing given by SNA Europe